




PROGRAMMING MENU SCHEME



7. SETTABLE VALUES FOR MULTIPLE CHOICE PARAMETERS


The various options for the multiple choice parameters are listed below. Default values are indicated with the * symbol.

- 7.1 C.O.n.F. (FUNCTIONING CONFIGURATION)**
 FUnC: Selects the functioning type: 0* = function of frequency value and totalizer value view. 1 = only function of frequency value view. 2 = only function of totalizer view.
 IrES: Enables the reset of the totalizer by panel and auxiliary digital input: 0* = enabled. 1 = disabled.
- 7.2 I.n.P.t. (DIGITAL INPUT)**
 tYPE: Selects the input type among the following: 1 = Reed, 2 = npn 2 wires, 3* = nnp 24 V (3 wires), 4 = pnp 24 V (3 wires), 5 = NAMUR, 6 = Photoelectric, 7 = Hall, 8 = 24 V Input, 9 = TTL Input, 10 = Variable Reluctance
- 7.3 S.C.R.L. (DISPLAYED VALUE SETTING)**
 FiLl: It sets the filter level. Admitted values: 0 = no filter, 1 - 20. Default: 3.
 Rwi: Number of samples on which the frequency measurement average is calculated. Admitted Values: 1 - 10. Default: 1.
- 7.4 R.L.1./R.L.2. (ALARM 1 AND ALARM 2 SETTING)**
 tYPE1/tYPE2: Sets the alarm type: 0* = Disabled Alarm, 1 = Alarm on the minimum threshold, 2 = Alarm on the maximum threshold, 3 = Retained alarm on the minimum threshold (reset is not automatic), 4 = Retained alarm on the maximum threshold (reset is not automatic).


- 0* = normally opened relay, 1 = normally closed relay.
- 7.5 O.U.t. (RETRANSMITTED OUTPUT SETTING)**
 tYPE: Sets the type of the retransmitted output: 1 = 0 - 10 V output, 2* = 4 - 20mA output, 3 = 0 - 20 mA output, 4 = totalizer digital output.
- 7.6 b.U.S. (RS485 SETTING)**
 Addr: Selects the slave Modbus address. Values from 1 to 255. Default: 1.
 PR: Selects the parity control of the serial communication: 0* = None, 1 = Even, 2 = Odd.
 dEL: Sets the response delay time. Values: 0 - 255. 0* = no delay, 1 = 1 pause, etc.
 bRId: Sets the Baudrate.
- 7.7 S.Y.S. (SYSTEM)**
 COnt: Sets the display contrast: values from 1 (minimum contrast) to 20 (maximum contrast). Default: 10.
 UPdn = 1200, 3 = 9600, 6* = 38400
 Totalizer Type: UP-counter or DOWN-counter, 7 = 57600
 0* = The totalizer increases of 0.01 at each rising edge of the digital input.
 1 = The totalizer decreases of a unit at each rising edge of the digital input.
- 7.6 t.o.t. (TOTALIZER SETTING)**
 rREt: Totalizer reducing ratio: value for which the totalizer will be divided. Admitted Values: 1..250. Default: 1.
- 7.8 d.F.L.t. (DEFAULT SETTING)**
 1 = Default setting for all the parameters.

MI001503-E ENGLISH -9/20

8. SETTING EXAMPLES



Now the minus sign is obtained replacing the first non-useful zero of the set value. By pressing the OK/MENU button the set value is confirmed:



A further pressure of the OK/MENU button, entails the return to the voice correspondent to the just modified parameter.

rLY1/rLY2: Sets the functioning of the correspondent relay (if optional card):